

QUESTION OF THE WEEK



Q

What do the numbers on the stick that stands in the pond between holes 10 & 11 represent?

A

That is the lake level of all the lakes. 12' is the control elevation of Worthington's lakes. Anything above 12' and water starts to leave via gravity. Sometimes water does not leave fast enough and the levels can rise above 12'. When levels continue to rise or if there is a storm, we close the lake interconnect between the driving range and pump to increase the out flow and decrease the lake levels. That gage is measured in 10th of a foot so 11.7' is 11' 7 1/2"